



EVO-STIK Decorators Flexible Filler

A WATER BASED ACRYLIC FILLER

Date: 20 July 2018

FactSheet No.: TDS00125

YOUR SMART ADVANTAGES

- Acrylic filler for draught proofing and filling fine cracks
- Ideal for joints where movement is likely e.g. between walls and ceilings, skirting boards and stairs
- Can be sanded, overpainted or papered over when dry

USES

EVO-STIK Decorators Flexible Filler is a fast drying paste which sets by evaporation of water when exposed to the atmosphere. It is ideal for filling low movement gaps around windows, door frames, skirting boards, coving, gaps in plasterboard and fine cracks prior to decorating and general filling of internal fixtures. EVO-STIK Decorators Flexible Filler can be sanded, overpainted or papered when set.

EVO-STIK Decorators Flexible Filler may be used externally provided it is allowed to set in warm, dry conditions with no chance of rain during the first 24 hours after application.

PRODUCT CHARACTERISTICS

Colour	White
Form	Ready to use paste, suitable for gun or knife application
Specific Gravity	1.48 approx.
Composition	A blend of acrylic polymers and selected fillers
Product Code	30811727 C20 cartridge x 12
Storage/Shelf Life	Store for up to 24 months from date of manufacture when stored in original, unopened packaging in cool, dry conditions within the temperature range of +5°C to +30°C.

TYPICAL PERFORMANCE DATA (Approx.)

Application Temperature	+5°C to +40°C
Service Temperature	-20°C to +70°C
Service Life	When applied correctly the filler will perform satisfactorily for approximately 15 years.
Coverage	Approx. 11 linear metres of 6mm diameter bead per C20 cartridge
Drying Times	Skin Formation: 15 to 60 minutes dependent on depth of filler, temperature and humidity. Through Dry: 24 hours depending on depth of filler, temperature and humidity.

DIRECTIONS FOR USE

IMPORTANT: Before using EVO-STIK Flexible Decorators Filler refer to the relevant Health & Safety Data Sheet, available at www.bostik.co.uk.

PREPARATION

1. Ensure that surfaces to which the product is to be applied are clean, dry, sound and free from dust, loose material and any other contaminants that may impair adhesion.
2. Very porous surfaces must be primed using a diluted PVA (5 parts water to 1 part PVA by volume), such as EVO-STIK Evo-Bond Building Adhesive. The primer must be allowed to dry.

APPLICATION

3. Unscrew the nozzle, and using a sharp knife, carefully cut off the dome of the cartridge, taking care not to damage the thread. Screw the nozzle onto the cartridge.
4. Cut off the tapered end of the nozzle at a 45° angle, to a width matching the gap to be sealed.
5. Fit the cartridge into the cartridge gun by pressing the release plate and pulling out the plunger. Insert cartridge and repeatedly squeeze the trigger until the filler appears.
6. Place the nozzle at the start of the gap, and gently squeeze the trigger. Push forward slowly, ensuring that contact is made by the filler with both sides of the gap. At the end of the run, release the trigger and press the plunger release plate of the gun.
7. Simply removing excess filler, immediately, with a flat blade will give a nice smooth finish.
8. When the product is used to fill gaps the temporary use of masking tape to define edges of the joint will often give a cleaner, neater look. Always remove masking tape, before the filler skins, which usually takes between 15 to 60 minutes, but is dependent upon drying conditions.
9. Painting of the filler should only be carried out once it has fully dried. Painting too early may lead to the paint cracking.
10. For fine filling and for applications less than 1mm, painting may be carried out in as little as 30 minutes.
11. When used for filling gaps around frames and skirtings' etc., where the filler may have a depth greater than 5mm, drying times will be much longer. Leave at least 24 hours before painting.

CLEANING

Uncured Filler:

12. Excess uncured filler should be carefully scraped away using a knife and the remaining film wiped away immediately with a clean cloth dampened with warm, soapy water.

Cured Filler:

13. There is not adequate solvent, carefully cut away excess with a very sharp knife. Do not use solvent to clean product from the skin – use soap and water.

PRECAUTIONS IN USE

EVO-STIK Decorators Flexible Filler will not be water resistant until it has dried. Painting after the product has dried will prolong the life of the product.

For any application not covered please contact Technical Services on +44 (0)1785 272625 or visit www.bostik.co.uk for advice.

Recommendations and suggestions are for guidance only, since conditions of use are completely beyond our control.

For health and safety instruction, first aid measures and spillage and disposal instructions, see separate Health and Safety Data sheet for EVO-STIK Decorators Flexible Filler, available at www.bostik.co.uk.

BOSTIK HOTLINE

Smart help +44 (0) 1785 272625



This disclaimer is issued by Bostik Limited ("the Company") and applies to the use of any products supplied by the Company ("the Products") displayed on this Technical Data Sheet ("TDS"). Please read this disclaimer carefully before using any of the Products. Using this TDS and/or the Product constitutes your acceptance of this disclaimer. Its contents shall prevail over any directions of use and any disclaimer and/or exclusion or limitation of liability of the Company which may appear on the packaging of the Products.

This disclaimer sets out the entire financial liability of the Company (including any liability for the acts or omissions of its employees, agents and sub-contractors) to any user of the Products ("Product User") in respect of any use made or resale by the Product User, of any of the Products in this TDS.

This disclaimer does not affect the Company's liability for death or personal injury arising from the Company's negligence in respect of the Products, nor its liability for fraud, or fraudulent misrepresentation, nor any other liability which cannot be excluded or limited under applicable law.

The Company's total liability however arising and whether caused by tort (including negligence and breach of statutory duty), breach of contract or otherwise, arising in connection with the use made or resale by the Product User of any of the Products in this TDS shall be limited to the price paid for the Product by the Product User.

The Company shall not be liable to the Product User for any pure economic loss, loss of profit, loss of business, depletion of goodwill or otherwise, in each case whether direct, indirect or consequential, or any claims (including in respect of personal injury insofar as not caused by the Company's negligence) for consequential compensation whatsoever (howsoever caused) which arise out of or in connection with the use made or resale by the Product User of any of the Products in this TDS.

The Company shall not be liable to the Product User in relation to any loss for any use which is inappropriate or use which is otherwise than in accordance with the relevant instructions for use of the Products in this TDS or on the Product. Product Users are advised to confirm the suitability of the Products by their own tests.

This TDS covers just one of a large range of products supplied by the Company.

Full information on these products and advice on application is freely available from our fully trained staff throughout the country. In addition, specialist technical advice is available from our Technical Services Department. This TDS supersedes all previous TDSs relating to the Products, and users of it must ensure that it is the current issue. Destroy all previous TDS, and if in any doubt, contact the Company, quoting the code number in the top right hand corner on the front of this document.

Sales	Tel: 0844 371 1192	Fax: 01785 241818	customer.service@bostik.com
Technical Advice	Tel: 0844 371 1197	Fax: 01785 272867	technical.service@bostik.com
Safety Data Sheets	Tel: 01785 272625	Fax: 01785 212962	sds.box-eu@bostik.com